


DOC JOHNSON®

iVibe™

select



iPlease

Instructions

To Turn On/Off iPlease's

Powerful Vibrations:

Locate raised button at the base of iPlease between the two metal charging contacts. Press and hold button for approximately 3 seconds until iPlease begins vibrating. Press and hold again to power off.

To Change the Vibration Pattern:

Press raised button at the base of iPlease without holding.

To Charge iPlease:

Plug charger into a USB power source and touch the metal charging contacts of iPlease and the heart-shaped magnetic charger together. Charger displays a flashing white light while properly connected and charging, and a solid white light when charging is complete.

To Clean and Maintain iPlease:

To clean, spray with Doc Johnson® Toy Cleaner or wash with a mild soap and warm water. Allow to dry completely before storing separately from other toys in a cool, dry place. Use with water-based lubricant/glide. *Doc Johnson® Toy Cleaner sold separately.