USAGE AND CARE

Training to increase sexual stamina and have more intense orgasms is done through a practice commonly known as "EDGING", which is done by self-stimulating almost to the point of orgasm and then stopping several times in a single session.

To prepare the OptiMALE™ Endurance ULTRASKYN™ Trainer™ Stroker for use:

Remove your new OptiMALE™ Endurance
ULTRASKYN™ Trainer™ Stroker from the plastic
bag and disassemble it to remove any additional
packaging materials from the ULTRASKYN™ tunnel
and other parts.



You may wish to clean the ULTRASKYN™ tunnel before use. To clean, spray with Doc Johnson® Toy Cleaner or wash with mild soap and warm water.

ULTRASKYN™ warms to body temperature with use and can be warmed in water prior to use.

To warm, remove the ULTRASKYN™ tunnel from the case, immerse in warm water until the tunnel reaches your preferred temperature, shake off excess water, and reinsert into the case.



Remove foam insert and discard before use.

To train with the OptiMALE™ Endurance ULTRASKYN™ Trainer™ Stroker:

Apply OptiMALE™ Water-Based Lubricant or your favorite glide/lubricant to your penis and the opening of the tunnel, and use the OptiMALE™ Endurance ULTRASKYN™ Trainer™ Stroker to stimulate your penis to erection.



When you are close to orgasm, stop stroking and either remove the Stroker or pull it towards the base of your penis. Try not to touch the head of your penis, where sensitive nerves are located. Stay still until your arousal level subsides. Inhale and exhale slowly and concentrate on being in control of your arousal and orgasm. When you no longer feel close to ejaculation, resume stroking. Repeat this process as much as you feel comfortable doing during your training session, applying pressure to the squeeze plate and adjusting the suction via the twistable end cap to control the intensity.



Over time, you will notice that you have more control and can endure longer, more intense periods of stimulation without ejaculating or losing your erection prematurely.

To clean and store the OptiMALE™ Endurance ULTRASKYN™ Trainer™ Stroker:

Gently pull from the top to remove the ULTRASKYN™ stroker tunnel from inside the case. The squeezegrip section may fall inside the case when this happens, because it is meant to be detached from its magnetic dock for cleaning.



Remove squeeze grip section from inside of case. Wash each section with Doc Johnson® Toy Cleaner* or mild soap and warm water and allow to air dry completely before storage/reassembly.

Dust the ULTRASKYN™ section with Doc Johnson® Refresh™ Powder®, reassemble the OptiMALE™ Endurance ULTRASKYN™ Trainer™ Stroker, and store in a cool, dry place with both caps on.

To reassemble after cleaning:

Return squeeze plate to its magnetic dock inside the case. Gently press down and twist the ULTRASKYN™ insert into the case until it returns to its original position. Replace caps at each end, and store in a cool. dry place.

* Doc Johnson® Toy Cleaner and Refresh™ Powder sold senarately

OPTIMIZE EVERY OPPORTUNITY




Also Available

SUCTION CUP ACCESSORY (sold separately)

Take your Endurance to the next level

- Super Strong Lever-Release Suction Cup
- Proprietary Base Screws on Like End Cap
- Powerfully Adheres to Any Smooth, Nonporous Surface
- Swivels and Bends for Custom Positioning
- Designed for Hands-Free Use
- Perfect for the Shower or Bath



SUCTION CUP ACCESSORY
0693-26-BX

DOCJOHNSON





Endurance Trainer ULTRASKYN Stroker