

DOCJOHNSON®

# iRide


## PLEASURE SEAT



### iSUCK



## Care and Usage Instructions

### To Operate on iSuck:

Hold  3 seconds or until LED display shows.

Press Button  to turn on suction. Continue pressing Button  to cycle through all 9 suction patterns.

Press Button  to turn on vibration functions. Continue pressing Button  to cycle through all 9 vibrating patterns.

To turn off iSuck, hold  until LED displays turn off.


### To Operate with Remote:

Hold  on iSuck 3 seconds or until LED display shows.

Press  on Remote.

Press Button  to turn on suction. Continue pressing Button  to cycle through all 9 suction patterns.

Press Button  to turn on vibration functions. Continue pressing Button  to cycle through all 9 vibration patterns.

To turn off remote, press .

### To Charge:

Plug included cable into a USB power source, then locate and place the cord on the magnetic charging port on the bottom of the iSuck.

Charge time: 120 Minutes

Usage Time: 45 Minutes

### Cleaning and Storage:

Spray with Doc Johnson Toy Cleaner or wash with mild soap and warm water. Allow to air-dry completely before storing separately from other toys in a cool, dry place. Use with water-based lubricant/glide. Doc Johnson Toy Cleaner sold separately.

**WARNING FOR VIBRATING PRODUCTS:** To avoid injury or aggravation of pre-existing conditions, this product should not be used on swollen or inflamed areas or skin lacerations. No medical claims are warranted or implied by the use of this product.

### FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

(2) Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



### PRODUCT USES AND WARNINGS:

To ensure the safe use of our products and to extend product life, before using our products please scan the QR code and review our Product Use Guidelines. Although all Doc Johnson products are designed and manufactured with great care, we urge our customers to practice sex toy safety. These Guidelines are also available on our website at <https://www.docjohnson.com/safety-practice>.

Hop on for a ride! The saddle-like iRide iSuck has two rideable sides: one sucking and one vibrating. Made from extra-cushioned health-grade silicone, both functions are operated by quiet-yet-powerful motors. The iRide iSuck is a rechargeable grinder with an included cable and is completely waterproof. It even comes with a wireless remote for a hands-free ride.